



FO-GRK4

Door Gasket Replacement Kit for Opel3 Fireplace

This kit includes the gasket and the high temperature sealant required to change the door gasket on your Opel3 fireplace. To do the replacement you will need a wire brush or a small scraper (like an old flat screwdriver).

INSTALLATION

❖ **WARNING: DO NOT REPLACE THE GASKET WHILE THE FIREPLACE IS HOT.**

1. Open the door and remove the existing gasket by grasping an end and pulling firmly.
2. Use a wire brush or the tip of a small scraper to clean the groove of any remaining high temperature sealant or bits of gasket. Any remnants of the old sealant will prevent the gasket from bonding to the door frame adequately.
3. Before applying the sealant, perform a dry fit of the gasket along the frame of the door. If it is too long, then bunch it together slightly, but do not cut the gasket. For the Opel3, the gasket should be thickest along the vertical portion on the hinge side of the door and also at the top of the door. If it is necessary to bunch up the gasket, do it in these locations.

If the gasket is too short, then stretch it gently until it covers the entire frame.

4. Fill the groove all the way around the door with a ¼" wide bead of high temperature sealant. Start at the bottom left corner of the door and proceed clockwise. Place the gasket into the groove all the way around the door frame, having someone assist by holding the gasket will make this easier. Be careful to prevent stretching it.
5. Shut the door tightly and leave it closed for at least 24 hours to allow the high temperature sealant to cure.



FO-GRK4

Trousse de remplacement du cordon d'étanchéité pour Opel3

Cette trousse comprend le cordon d'étanchéité et le scellant à haute température nécessaire au remplacement du cordon d'étanchéité de la porte de votre foyer Opel3. Pour effectuer le remplacement, vous aurez besoin d'une brosse à poils d'acier ou d'un petit grattoir (un vieux tournevis plat par exemple).

INSTALLATION

MISE EN GARDE : NE PAS REMPLACER LE CORDON D'ETANCHEITE LORSQUE LE FOYER EST CHAUD.

1. Enlevez l'ancien cordon d'étanchéité en saisissant une extrémité et en tirant fermement dessus.
2. Utilisez une brosse ou un grattoir pour enlever le vieux scellant à haute température et les restants du cordon d'étanchéité dans la rainure. Assurez-vous de bien retirer tout le vieux scellant, car il pourrait empêcher le nouveau cordon d'étanchéité d'adhérer adéquatement au contour de la porte.
3. Remplissez la rainure sur les quatre côtés de la porte avec une couche de scellant à haute température de ¼" de large. Placez le cordon d'étanchéité dans la rainure en le déposant simplement sur le scellant à haute température sans l'étirer. Commencez par installer le cordon d'étanchéité à la base de la porte et continuez dans le sens des aiguilles d'une montre.

Si le cordon d'étanchéité vous semble trop court, étirez-le légèrement sur toute sa longueur afin d'atteindre la longueur nécessaire. Ne pas étirer ni compacter inégalement le cordon d'étanchéité, car la porte perdrait de son étanchéité.

4. Fermez la porte et gardez-la fermée au moins 24 heures pour permettre au scellant à haute température de sécher.

Liste de contrôle/ Check List:

- 90" cordon d'étanchéité rond 3/4" / Round gasket 3/4" (971013)
- 1 Scellant à haute température / High temperature sealant 85g (920005)
- Notice d'installation et liste de contrôle/ Instructions and check list



INITIALES
INITIALS